



**UVEX Safety Goggles**



**Area of Application and Features**

- **Features:** Special version (based on the requirements of Berner International) of the well known UVEX Safety Goggle, full vision, non-fogging and can be worn over corrective glasses. The elastic strap ensures a firm and fit.
- **Area of application:** Protection from mechanical risks, liquids and coarse dust.
- **Protection capacity:** Does not provide protection from high-speed particles, laser beams, temperatures of over 55°C, arcing faults, molten metals.
- **Replacement interval:** Immediately in the event of visible contamination!
- **Before use:** Check for any damage! Do not use goggles if label is absent or illegible.
- **Disposal:** If used in connection with cytostatics: waste requiring supervision (waste code: 18 01 04 in accordance with 2000/532/EC); in the event of heavy contamination, waste requiring special supervision (waste code: 18 01 08\* in accordance with 2000/532/EC); collect and dispose of waste separately!

<sup>1)</sup>: Personal Protective Equipment

**Type**





<b>Size</b>	Universal
<b>Item-no.</b>	121405
<b>Colour</b>	Transparent

**Frame Marking**

<b>W</b>	Code letter manufacturer
<b>166</b>	Number of standard
<b>DIN</b>	Certification
<b>CE</b>	EC-conformity
<b>0196</b>	Notified body

**Lens Marking**

<b>W</b>	Code letter of manufacturer
<b>1</b>	Optical class
<b>K</b>	Resistance to fogging
<b>DIN</b>	Certification
<b>CE</b>	EC-conformity
<b>0196</b>	Notified body

<b>Care instructions</b>	
<p><b>Cleaning:</b> Using clean water and household washing-up liquid (no lye, acids or solvents!). Avoid a strong mechanical action when cleaning (scratched surface = high proportion of stray light).</p> <p><b>Disinfection:</b> Item can be disinfected with any standard disinfectant.</p>	
	<b>CE-Mark</b>
<p>CE-marking in accordance with <b>PPE Directive 89/686/EEC</b> for PPE (category II). The type test performed was based on EN 166. Produced by: UVEX Arbeitsschutz GmbH, Fürth, Germany.</p>	
<b>0196</b>	<b>Notified Body „0196“</b>
<p>DIN CERTCO, Gartenstr. 133, D-73430 Aalen, Germany.</p>	
	<b>Quality Management System</b>
<p>Our <b>Quality management system</b> is <b>tested and certified</b> by TÜV Product Service GmbH (a certification body accredited by the German Accreditation Council) in accordance with DIN EN ISO 9001:2008. Regular <b>audits and production site inspections</b> guarantee the quality of our products.</p>	
	<b>Storage and Transport Conditions</b>
<ul style="list-style-type: none"><li>▪ Dark (protect from direct UV light and sunlight)</li><li>▪ Cool (+5 to +40°C)</li><li>▪ Dry</li><li>▪ No contact with pointed and/or sharp objects</li></ul>	
	<b>Shelf Life</b>
<ul style="list-style-type: none"><li>▪ 5 years from date of manufacture</li></ul>	